

Anybus Registers

Using the provided configuration file. Profibus address set to 42.

Registers

8 Digit Display, Address 01 Registers:

0x0200, 0x0201, 0x0202, 0x0203, 0x0204, 0x0205, 0x0206, 0x0207, 0x0208, 0x0209

Examples

Register	Value
0x0200	0x31
0x0201	0x32
0x0202	0x33
0x0203	0x34
0x0204	0x00
0x0205	0x00
0x0206	0x00
0x0207	0x00

Display



The value of register 0x200 is the most significant character.
Data justified right on the display.

Register	Value
0x0200	0x31
0x0201	0x32
0x0202	0x33
0x0203	0x34
0x0204	0x35
0x0205	0x36
0x0206	0x00
0x0207	0x00

Display



Data length fits the display.

Register	Value
0x0200	0x31
0x0201	0x32
0x0202	0x33
0x0203	0x34
0x0204	0x35
0x0205	0x36
0x0206	0x37
0x0207	0x38

Display



Data length too long for display. Register 0x200 and 0x201 values are lost.